

Dismounting of Rudder Hallberg-Rassy 26, English translation

- 1) Remove the putty at the lower bearing (3 and 4)
- 2) Ease the two bolts on fitting 2
- 3) Ease the four bolts on fitting 3
- 4) Lift the rudder off. Remove the bolts (possibly rivets) at fitting 4
- 5) Take the fitting to a mechanical work shop in order to have a larger pin installed.

Re-installing the rudder:

- 1) Install first fitting 2, then fitting 4 both with some putty like for example Plastic Padding. Take a long pole or metal pipe to make sure the fittings are in line.
- 2) Install fittings 1 and 3. Install the rudder and secure the fittings.

DEMONTERING AV RÖDERBESLAG

1. Tag bort spackel på nedersta beslagen (3)(4)
2. Lossa de två bultarna på beslag (3) ev. slifpa bort nitar
3. Lossa de fyra bultarna på beslag (2)
4. Lyft av rodret. Tag bort bultarna ev. nitarna på beslag (4)
5. Sedan kan ni ta beslagen till en mekanisk verkstad för att montera en större tapp.

Montering av röder

Essmatur A eller  
rostfrihetspropellerakselstål

1. Montera beslag (2) därefter (4) med lite plastic padding tag sen en rörstump eller kvätskäft och centrera beslagen i en rät linje. Mont, (I) (3) häng sen på röder och dra fast.

Rät linje kväst eller rör e.x.

